

## Bulk Tank System<sup>®</sup>

## Spent Oil Tanks: 200L & 400L Models

### 200L SPECIFICATION

Model	0200M / 0200MH1EA	Opening	260 x 450mm
Capacity	200L	Height	1010mm
Weight	30kg	Width	450mm
Lid Clearance H	1270mm	Length	900mm

### 400L SPECIFICATION

Model	0400M / 0400MH1EA	Opening	350 x 600mm
Capacity	400L	Height	1000mm
Weight	40kg	Width	600mm
Lid Clearance H	1350mm	Length	990mm

### Features

- Large storage capacity available
- Available with or without heater for use with hard and soft oils
- Robust Stainless Steel design for use in commercial kitchens
- Mobile design allowing for movement of the vessel to meet your oil collection requirements

### Safety

- Reduces manual handling of oil for employees
- Industrial castors for safe transportation
- Ergonomic handles located on two sides of the vessel assist mobility and prevent vessel damage
- Lock down lid prevents oil spills during transportation, reducing the likelihood of slips or falls due to spilled oil

### Savings

- Large storage volume reduces the frequency of collection required
- Proven Labour savings

### Security

- Vessel suitable for indoor oil storage, eliminating the need for employees to leave the establishment to dispose of used oil
- Filter baskets are locked in place to prevent the oil from being stolen



### Sanitation

- Large opening reduces the likelihood of spills
- Castors allow for the unit to be moved to allow for cleaning and area wash down


The Oil Kaddy System<sup>®</sup> is exclusively available from Auscol Pty Ltd

**1800 629 476**      **www.auscol.com**

## Procedure

 **It is recommended that gloves and non slip footwear be worn!**

1. Ensure the area surrounding the tank is clean and tidy and free of obstacles.
2. Fully open the tank lid and remove any content that may be present in the crumb basket.
3. When the oil is at a suitable temperature to be safely handled, carefully pour or pump the oil into the crumb basket.
4. Remove any crumbs from the basket when oil transfer is complete and close the lid.
5. Clean any spills or rubbish on or around the storage tank.



## If the tank is equipped with a heater...

Carefully move the tank to an open area to reveal the heater power socket positioned at the bottom of the tank. Connect the supplied power cord to the tank heater as shown in the diagram above and carefully reposition the tank back to its parked position. Plug the other end of the power cord into a power point and turn it on.

It should be ensured that the vessel is connected to a RCD protected power outlet at all times. If in doubt please contact your stores electrical contractor, or alternatively Auscol on the number shown below.

## Is the Bin full?

Call the Auscol collection service: 1800 629 476



## **AVOID CONTAMINATION!**

Auscol is an edible oil and fat recycler - not a waste collector. Please prevent contaminants such as detergents or any other liquids other than Spent Cooking Oils and Fats from entering the collection tank.

The Oil Kaddy System<sup>®</sup> is exclusively available from Auscol Pty Ltd

**1800 629 476** [www.auscol.com](http://www.auscol.com)